

Assembly Instruction for PL259-S-CL213

Slide Locknut onto cable

Trim Jacket back 30 mm



Cut Braid to 15 mm long



Slide on clamping ring



Fan out braid to allow collet fitting



Slide Collet over inner dielectric



Press Collet firmly into braid



**Trim Braid around collet
Cut dielectric 1 mm from end**



Fit conductor into centre Pin



Push connector body on firmly



check centre conductor length



slide cable locknut to body



Tighten locknut with 2 wrenches

